




**External Rewinder ER1
External Rewinder ER4/300
for Transfer Printer
BP-PR PLUS Series**

Spare Parts List





W.H. Brady
Lindestraat 21
Industriepark C3
9240 Zele Belgium
Tel.: +32 52 457 811
e-mail: support@brady.be



Identification Solutions Division
6555 W. Good Hope Road
PO Box 2131
Milwaukee, WI 53201 U.S.A.
Phone: 1-800-537-8791
Fax: 1-800-292-2289

References for Spare Parts Ordering

1. Please address spare parts orders to:

W.H. Brady
Lindestraat 21
Industriepark C3
9240 Zele Belgium
Tel.: +32 52 457 811
e-mail: support@brady.be

2. Orders will be accepted in writing only. They must contain the following information:

- customers name and address
- customers number (if known)
- serial number of the device
- part number
- name of item




Make sure to update your stock of spare parts regularly.

Overview of the Spare Parts Drawings

Page	Assembly	Serial No.	
ER1-1.0	Chassis	all	x
ER1-2.0	Rewind Shaft	all	x
ER4/300-1.0	Chassis	all	x
ER4/300-2.0	Rewind Shaft	all	x

[to the Overview](#)




ER1	<i>ER4/300</i>
------------	----------------

No.	Part-No.	Description	Pieces
1	5945869	Cover	1
2	5945716	Spindle	1
3	5902241	Screw DIN7984-M4x10-8.8-galZn	2
4	5903003	Washer DIN125-A4.3-galZn	2
5	5903507	E-Ring DIN6799-3.2-galZn	1
6	5945866	Center Mounting Plate	1
7	5902168	Screw DIN912-M3x5-8.8-galZn	1
8	5903009	Washer DIN9021-3.2-galZn	1
9	5945881	Blind	1
10	5533089	Flange	1
11	5904510	Set Screw DIN916-M3x5-45H	1
12	5902018	Screw DIN912-M3x16-8.8-galZn	1
13	5905010	Spring Z-060-AX	1
14	5520854	Spring Bolt	1
15	5903094	Washer DIN988-8x12x0.2	3
16	5945729	Bushing	1
17	5902358	Screw DIN7984-M4x6-8.8-galZn	2
18	5948197	PCB, rewinder control, complete	1
19	5902501	Nut DIN934-M4-8-galZn	1
20	5903011	Toothed Washer DIN6797-A4.3-galZn	1
21	5945713	Center Pin	1
22	5902348	Screw DIN7984-M4x16-8.8-galZn	3
23	5903113	Washer 4.3x9.0x1.4	2
24	5945737	Connection	1
25	5902241	Screw DIN7984-M4x10-8.8-galZn	2
26	5945735	Guide	1
27	5902410	Screw DIN7984-M3x12-8.8-galZn	3
28	5945730	Lever	1
29	5945711	Roller	1
30	5903516	Snap Ring DIN471-8x0.8-galZn	1
31	5905780	Foot 15.9x7.1	1
32	5902241	Screw DIN7984-M4x10-8.8-galZn	1
33	5530789	Switch	1
34	5945733	Foot	2
35	5902241	Screw DIN7984-M4x10-8.8-galZn	4

[to the Overview](#)

ER1	ER4/300
-----	---------




No.	Part-No.	Description	Pieces
1	5905772	Belt 80XL 037	1
2	5904528	Set Screw DIN913-M3x4-45H	2
3	5945724	Gear 12XL037-F6	1
4	5903540	Snap Ring DIN471-15x1	1
5	5903104	Washer DIN988-15x21x0.2	1
6	5903084	Washer DIN988-15x21x0.5	2
7	5901103	Ball Bearing DIN625-F6902-ZZ	2
8	5902178	Screw DIN912-M6x20-8.8-galZn	3
9	5903040	Washer DIN125-A6.4-galZn	3
10	5900537	Spacer Bushing St M6x5-galZn	3
11	5945880	Motor	1
12	5948190	Rewind Shaft	1
13	5948130	Spring	1
14	5902358	Screw DIN7984-M4x6-8.8-galZn	2
15	8910053	Square Nut M4 8mm	4
16	5902089	Thumbscrew DIN653-M4x12-5.8-galZn	2
17	5520697	Adapter Ø 75	2
18	5520698	Spring	2
19	5902022	Screw DIN7985-M4x10-4.8-H-galZn	2
20	5520211	Adapter Ø 75	2 A)
21	5537815	Flange	1
22	5520892	Thumbscrew	1
23	8910053	Square Nut M4 8mm	1
24	5520860	Stopper	1
25	5537816	Flange	1 A)
26	5530729	Clamp	1

A) Assembly

[to the Overview](#)


ER4	ER4/300
-----	---------



No.	Part-No.	Description	Pieces
1	5530789	Switch	1
2	5948164	Line Power Supply	1
3	5901509	Cable Clamp 6x11x5	1
4	5948155	Distance bolt	4
5	5948163	Insulating Plate	1
6	5911112	Power Supply	1
7	5900045	Distance bolt	4
8	5948154	Cover	1
9	5902168	Screw DIN912-M3x5-8.8-galZn	4
10	5948165	Fused Main Connector	1
11	5903003	Washer DIN125-A4.3-galZn	2
12	5902501	Nut DIN934-M4-8-galZn	2
13	5902358	Screw DIN7984-M4x6-8.8-galZn	2
14	5948197	PCB, rewinder control, complete	1
15	5948536	Bolt	3
16	5905138	Foot	2
17	5903516	Snap Ring DIN471-8x0.8-galZn	1
18	5901090	Ball Bearing DIN625-F608-ZZ	1
19	5902241	Screw DIN7984-M4x10-8.8-galZn	1
20	5903003	Washer DIN125-A4.3-galZn	1
21	5948537	Blind	1
22	5905010	Spring Z-060-AX	1
23	5948538	Pin	1
24	5904522	Set Screw DIN915-M5x14-45H	1
25	5948539	Retainer	1
26	5901090	Ball Bearing DIN625-F608-ZZ	1
27	5948527	Lever, complete	1
28	5945711	Roller	1
29	5903516	Snap Ring DIN471-8x0.8-galZn	1
30	5948545	Cover	1
31	5903003	Washer DIN125-A4.3-galZn	2
32	5902241	Screw DIN7984-M4x10-8.8-galZn	2
33	5902510	Nut DIN934-M4-CuZn-galNi	1
34	5903011	Toothed Washer DIN6797-A4.3-galZn	2
35	5903033	Washer DIN125-A4.3-CuZn-galNi	1
36	5530777	Wire with connectors to ground	1
37	5917072	Ground Connector DIN46244-A4-4.8	1
38	5903033	Washer DIN125-A4.3-CuZn-galNi	1
39	5903011	Toothed Washer DIN6797-A4.3-galZn	2
40	5902510	Nut DIN934-M4-CuZn-galNi	1
41	5948514	Center Mounting Plate	1
42	5948546	Foot	1
43	5948541	Foot	1
44	5902241	Screw DIN7984-M4x10-8.8-galZn	4
45	5905652	Foot 20.6x20.6x7.6 ws	4

[to the Overview](#)

ER1	ER4/300
-----	---------



No.	Part-No.	Description	Pieces
1	5904515	Set Screw DIN913-M4x8-45H	4
2	5533024	Tooth Gear 20	1
3	5905964	Belt 96XL037 z=48	1
4	5903511	E-Ring DIN6799-12-oxbr	1
5	5903084	Washer DIN988-15x21x0.5	1
6	5901103	Ball Bearing DIN625-F6902-ZZ	2
7	5948535	Gear 20-teethed	1
8	5902361	Screw DIN7984-M6x16-8.8-galZn	3
9	5903040	Washer DIN125-A6.4-galZn	3
10	5948590	Motor	1
11	5902348	Screw DIN7984-M4x16-8.8-galZn	4
12	5948531	Guide, complete	1
13	5902489	Screw DIN7984-M4x8-8.8-galZn	2
14	5903003	Washer DIN125-A4.3-galZn	2
15	5948156	Adapter Plate	1
16	5948159	Guide, complete	1
17	5948522	Rewind Shaft, complete	1
18	5948130	Spring	1
19	5902358	Screw DIN7984-M4x6-8.8-galZn	2
20	5520211	Adapter Ø 75	2 A)
21	8910053	Square Nut M4 8mm	4
22	5902089	Thumbscrew DIN653-M4x12-5.8-galZn	2
23	5520697	Adapter Ø 75	2
24	5520698	Spring	2
25	5902022	Screw DIN7985-M4x10-4.8-H-galZn	2
26	5520853	Flange Ø 300	1
27	5520866	Flange Ø 300	1
28	5520892	Thumbscrew	1
29	8910053	Square Nut M4 8mm	1
30	5520860	Stopper	1
31	5530729	Clamp	1

A) Assembly

Spare Parts Register

Part.-No.	Description	Figure in Spare Parts List Page
5520211	Adapter Ø 75	ER1-2.0, ER4/300-2.0
5520697	Adapter Ø 75	ER1-2.0, ER4/300-2.0
5520698	Spring	ER1-2.0, ER4/300-2.0
5520853	Flange Ø 300	ER4/300-2.0
5520854	Spring Bolt	ER1-1.0
5520860	Stopper	ER1-2.0, ER4/300-2.0
5520866	Flange Ø 300	ER4/300-2.0
5520892	Thumbscrew	ER1-2.0, ER4/300-2.0
5530729	Clamp	ER1-2.0, ER4/300-2.0
5530777	Wire with connectors to ground	ER4/300-1.0
5530789	Switch	ER1-1.0, ER4/300-1.0
5533024	Tooth Gear 20	ER4/300-2.0
5533089	Flange	ER1-1.0
5537815	Flange	ER1-2.0
5537816	Flange	ER1-2.0
5550611	Power Cable	(ER4/300)
5900045	Distance bolt	ER4/300-1.0
5900537	Spacer Bushing St M6x5-galZn	ER1-2.0
5901090	Ball Bearing DIN625-F608-ZZ	ER4/300-1.0
5901103	Ball Bearing DIN625-F6902-ZZ	ER1-2.0, ER4/300-2.0
5901509	Cable Clamp 6x11x5	ER4/300-1.0
5902018	Screw DIN912-M3x16-8.8-galZn	ER1-1.0
5902022	Screw DIN7985-M4x10-4.8-H-galZn	ER1-2.0, ER4/300-2.0
5902089	Thumbscrew DIN653-M4x12-5.8-galZn	ER1-2.0, ER4/300-2.0
5902168	Screw DIN912-M3x5-8.8-galZn	ER1-1.0, ER4/300-1.0
5902178	Screw DIN912-M6x20-8.8-galZn	ER1-2.0
5902241	Screw DIN7984-M4x10-8.8-galZn	ER1-1.0, ER4/300-1.0
5902348	Screw DIN7984-M4x16-8.8-galZn	ER1-1.0, ER4/300-2.0
5902358	Screw DIN7984-M4x6-8.8-galZn	ER1-1.0, ER1-2.0, ER4/300-1.0, ER4/300-2.0
5902361	Screw DIN7984-M6x16-8.8-galZn	ER4/300-2.0
5902410	Screw DIN7984-M3x12-8.8-galZn	ER1-1.0
5902489	Screw DIN7984-M4x8-8.8-galZn	ER4/300-2.0
5902501	Nut DIN934-M4-8-galZn	ER1-1.0, ER4/300-1.0
5902510	Nut DIN934-M4-CuZn-galNi	ER4/300-1.0
5903003	Washer DIN125-A4.3-galZn	ER1-1.0, ER4/300-1.0, ER4/300-2.0
5903009	Washer DIN9021-3.2-galZn	ER1-1.0
5903011	Toothed Washer DIN6797-A4.3-galZn	ER1-1.0, ER4/300-1.0
5903033	Washer DIN125-A4.3-CuZn-galNi	ER4/300-1.0
5903040	Washer DIN125-A6.4-galZn	ER1-2.0, ER4/300-2.0
5903084	Washer DIN988-15x21x0.5	ER1-2.0, ER4/300-2.0
5903094	Washer DIN988-8x12x0.2	ER1-1.0
5903104	Washer DIN988-15x21x0.2	ER1-2.0
5903113	Washer 4.3x9.0x1.4	ER1-1.0
5903507	E-Ring DIN6799-3.2-galZn	ER1-1.0
5903511	E-Ring DIN6799-12-oxbr	ER4/300-2.0
5903516	Snap Ring DIN471-8x0.8-galZn	ER1-1.0, ER4/300-1.0
5903540	Snap Ring DIN471-15x1	ER1-2.0
5904510	Set Screw DIN916-M3x5-45H	ER1-1.0
5904515	Set Screw DIN913-M4x8-45H	ER4/300-2.0
5904522	Set Screw DIN915-M5x14-45H	ER4/300-1.0
5904528	Set Screw DIN913-M3x4-45H	ER1-2.0

Part.-No.	Description	Figure in Spare Parts List Page
5905010	Spring Z-060-AX	ER1-1.0, ER4/300-1.0
5905138	Foot	ER4/300-1.0
5905652	Foot 20.6x20.6x7.6 ws	ER4/300-1.0
5905772	Belt 80XL 037	ER1-2.0
5905780	Foot 15.9x7.1	ER1-1.0
5905964	Belt 96XL037 z=48	ER4/300-2.0
5911112	Power Supply	ER4/300-1.0
5917072	Ground Connector DIN46244-A4-4.8	ER4/300-1.0
5945711	Roller	ER1-1.0, ER4/300-1.0
5945713	Center Pin	ER1-1.0
5945716	Spindle	ER1-1.0
5945724	Gear 12XL037-F6	ER1-2.0
5945729	Bushing	ER1-1.0
5945730	Lever	ER1-1.0
5945733	Foot	ER1-1.0
5945735	Guide	ER1-1.0
5945737	Connection	ER1-1.0
5945866	Center Mounting Plate	ER1-1.0
5945869	Cover	ER1-1.0
5945880	Motor	ER1-2.0
5945881	Blind	ER1-1.0
5948130	Spring	ER1-2.0, ER4/300-2.0
5948154	Cover	ER4/300-1.0
5948155	Distance bolt	ER4/300-1.0
5948156	Adapter Plate	ER4/300-2.0
5948159	Guide, complete	ER4/300-2.0
5948163	Insulating Plate	ER4/300-1.0
5948164	Line Power Supply	ER4/300-1.0
5948165	Fused Main Connector	ER4/300-1.0
5948190	Rewind Shaft	ER1-2.0
5948197	PCB, rewinder control, complete	ER1-1.0, ER4/300-1.0
5948514	Center Mounting Plate	ER4/300-1.0
5948522	Rewind Shaft, complete	ER4/300-2.0
5948527	Lever, complete	ER4/300-1.0
5948531	Guide, complete	ER4/300-2.0
5948535	Gear 20-teethed	ER4/300-2.0
5948536	Bolt	ER4/300-1.0
5948537	Blind	ER4/300-1.0
5948538	Pin	ER4/300-1.0
5948539	Retainer	ER4/300-1.0
5948541	Foot	ER4/300-1.0
5948545	Cover	ER4/300-1.0
5948546	Foot	ER4/300-1.0
5948590	Motor	ER4/300-2.0
8910053	Square Nut M4 8mm	ER1-2.0, ER4/300-2.0
9109175	Packaging	(ER1)
9109178	Packaging	(ER4/300)